Maintenance Code

W/B+Steam - Clean with water-based cleanser, diluted household bleach, or steam clean.

General Recommendations

Treat stains promptly. The longer a stain remains on the textile, the more difficult it will be to remove. A professional furniture cleaning service is recommended. Vacuum regularly using the proper attachment to avoid pilling and/or clean with water-based cleanser, diluted household bleach, or steam as needed. Always pre-test any cleaning method in an inconspicuous area. Several light applications of a cleaning agent are less harmful than a single concentrated application. Repeat stain treatment several times if necessary.

Do not use solvent-based cleaning agents such as lacquer thinners, nail polish remover, or pine oil. These agents my cause discoloration over time.

Do not over saturate the textile or let water pool in seams.

Stain Treatment - Water-Based Cleansers

- For oil and water-based stains, use a clean, soft, white cloth, a natural sponge, or a nylon soft-bristle brush with lukewarm, soapy water. Brush the stain with light, quick strokes. Avoid a scrubbing motion and work from the edge of the stain toward the center.

- For tougher oil-based stains, dab a liberal amount of rubbing alcohol on the stain and let it sit for one minute before applying a water based cleanser. Confirm the construction of your textile is bleach cleanable. If so, and additional stain treatment is needed, use a 10% solution of diluted household bleach. Thoroughly rinse with cool, clean water and vacuum extract the textile to remove any residue.

- For solid stains (e.g. mud) allow the stain to dry thoroughly and gently break up any hardened areas. Use a nylon, soft bristle brush to remove all loose particles.

- For insoluble stains (e.g. chewing gum, candle wax, etc.), use a plastic bag filled with ice to rub the stain until the substance becomes brittle. Use a clean, dull, flat knife to gently remove the substance. If the stain persists, blot the area with a clean, soft, white cloth, or natural sponge and lukewarm soapy water.

- For blood and bodily fluid stains, follow the oil-based stain treatment above. If the stain persists, gently dab a pH-neutral cleanser, upholstery spot cleaner, or an equal mixture of water and enzyme detergent (e.g. laundry detergent) on the stain and let it sit for one minute.

Rinse all stain treatments thoroughly with a natural sponge moistened slightly with cool, clean water and completely remove all cleaning solution residue as left over residue can attract soil over time. Extra care should be taken when cleaning dark colors of woven textiles to avoid creating light marks that can be caused by color transfer. Avoid excess rubbing to prevent discoloration and damage to the face of the material.

Allow the textile to dry thoroughly and vacuum before using.

Stain Treatment - Steam Cleaning

Before cleaning, fill steam cleaner with fresh, clear water. Pre-treat stains with a professional steam cleaning pre-treatment solution or an equal mixture of enzyme powder detergent and water.

Healthcare Recommendations

Healthcare facilities should follow safety protocols for biological hazards and/or anti-viral treatments during the cleaning process. For a complete list of approved hospital grade cleansers, contact your sales representative.

Note

Maharam can neither guarantee, nor take responsibility for specific results. Under no circumstances shall Maharam be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling, or exposure of any chemicals used in connection with maintenance. Information relating to chemicals/cleaning solvents, environmental use, and human exposure should be reviewed with appropriate suppliers.

maharam

Approved Cleaners

3M The Clorox Company 3M HB Quat Disinfectant Cleaner Concentrate Clorox Healthcare Bleach Germicidal Wipe 3M HB Quat Disinfectant Cleaner RTU Yarious 3M Out Disinfectant Cleaner Concentrate 1:10 Solution of Diluted Household Bleach 3M Quat Disinfectant Cleaner Concentrate 1:10 Solution of Diluted Household Bleach 3M Quat Disinfectant Cleaner Concentrate 1:4 Solution of Diluted Household Bleach Water Based Or Solvent Based Cleaners Water Based Or Solvent Based Cleaners Amsan Virox 5 Concentrate Sureblend Hospital Disinfectant Cleaner Virox 5 Concentrate Buckeye International Waxie Enterprises Sanicare Quat 256 Waxie Quat-128 Disinfectantcleaner Diversey Wood Wyant Expose II 256 Ultraquat Germicidal Detergent Virex II 256 Image: Solution of Dilute Household Bleach Virex Tb Image: Solution of Diluted Household Bleach Vira 1 Solution of Diluted Household Bleach Virex 1256 Image: Solution of Diluted Household Bleach Virex II 256 Image: Solution of Diluted Household Bleach Virex Tb Image: Solution of Diluted Household Bleach Sani-Cloth Bleach Germicidal Bleach Wipes	
3M HB Quat Disinfectant Cleaner RTU 3M Neutral Quat Disinfectant Cleaner Concentrat 3M Quat Disinfectant Cleaner Concentrate 1:10 Solution of Diluted Household Bleach 3M Quat Disinfectant Cleaner Concentrate Amsan Sureblend Hospital Disinfectant Cleaner Virox Technologies Virox 5 Concentrate Buckeye International Sanicare Quat 256 Scenturion Odor Counteractant Diversey Expose II 256 Virex II 256 Ecolab A-456-N Virex Tb Macine Industries Micro-Kill Bleach Cermicidal Bleach Wipes Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth Plus Germicidal Disposable Cloth	25
3M Neutral Quat Disinfectant Cleaner Various Concentrat 1:10 Solution of Diluted Household Bleach 3M Quat Disinfectant Cleaner Concentrate 1:4 Solution of Diluted Household Bleach Amsan Virox Technologies Sureblend Hospital Disinfectant Cleaner Virox 5 Concentrate Buckeye International Virox 5 Concentrate Sanicare Quat 256 Waxie Enterprises Scenturion Odor Counteractant Wood Wyant Diversey Wood Wyant Expose II 256 Ultraquat Germicidal Detergent Vira	
Concentrat 1:10 Solution of Diluted Household Bleach 3M Quat Disinfectant Cleaner Concentrate 1:4 Solution of Diluted Household Bleach Amsan Water-Based Or Solvent Based Cleaners Sureblend Hospital Disinfectant Cleaner Virox Technologies Buckeye International Waxie Enterprises Sanicare Quat 256 Waxie Quat-128 Disinfectantcleaner Diversey Wood Wyant Expose II 256 Ultraquat Germicidal Detergent Virex II 256 Ultraquat Germicidal Detergent Johnson Wax	
3M Quat Disinfectant Cleaner Concentrate 1:4 Solution of Diluted Household Bleach Amsan Virox Technologies Sureblend Hospital Disinfectant Cleaner Virox 5 Concentrate Buckeye International Waxie Enterprises Sanicare Quat 256 Waxie Quat-128 Disinfectantcleaner Diversey Wood Wyant Expose II 256 Ultraquat Germicidal Detergent Virex II 256 Vira Johnson Wax Virex Tb Medline Industries Micro-Kill Bleach Germicidal Disposable Wipe Sani-Cloth Bleach Germicidal Disposable Cloth Sani-Cloth Plus Germicidal Disposable Cloth	
Amsan Water- Based Or Solvent Based Cleaners Sureblend Hospital Disinfectant Cleaner Virox Technologies Buckeye International Waxie Enterprises Sanicare Quat 256 Waxie Quat-128 Disinfectantcleaner Diversey Wood Wyant Expose II 256 Ultraquat Germicidal Detergent Virex II 256 Ultraquat Germicidal Detergent Johnson Wax	
Amsan Sureblend Hospital Disinfectant Cleaner Wirox Technologies Virox 5 Concentrate Buckeye International Sanicare Quat 256 Scenturion Odor Counteractant Diversey Expose II 256 Virox 128 Disinfectantcleaner Virex II 256 Ecolab A-456-N Vira Johnson Wax Virex Tb Medline Industries Micro-Kill Bleach Cermicidal Disposable Wipe Sani-Cloth HB Germicidal Disposable Cloth	
Sureblend Hospital Disinfectant Cleaner Virox Technologies Buckeye International Virox 5 Concentrate Buckeye International Waxie Enterprises Scenturion Odor Counteractant Waxie Quat-128 Disinfectantcleaner Diversey Wood Wyant Expose II 256 Ultraquat Germicidal Detergent Virex II 256 Iltraquat Germicidal Detergent Vira International Johnson Wax International Virex Tb International Medline Industries International Micro-Kill Bleach Cermicidal Disposable Wipe International Sani-Cloth HB Germicidal Disposable Cloth International	
Wirox 5 Concentrate Buckeye International Sanicare Quat 256 Scenturion Odor Counteractant Waxie Enterprises Waxie Quat-128 Disinfectantcleaner Diversey Expose II 256 Virex II 256 Ecolab A-456-N Viva Johnson Wax Virex Tb Medline Industries Micro-Kill Bleach Cermicidal Disposable Wipe Sani-Cloth Bleach Germicidal Disposable Cloth	
Buckeye International Sanicare Quat 256 Scenturion Odor Counteractant Diversey Expose II 256 Virex II 256 Ecolab A-456-N Viva Johnson Wax Virex Tb Medline Industries Micro-Kill Bleach Cermicidal Disposable Wipe Sani-Cloth Bleach Germicidal Disposable Cloth	
Sanicare Quat 256 Waxie Enterprises Scenturion Odor Counteractant Waxie Quat-128 Disinfectantcleaner Diversey Wood Wyant Expose II 256 Ultraquat Germicidal Detergent Virex II 256 Ultraquat Germicidal Detergent A-456-N Viva Viva Medline Industries Micro-Kill Bleach Cermicidal Bleach Wipes Micro-Kill Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Disposable Cloth Sani-Cloth Plus Germicidal Disposable Cloth	
Scenturion Odor Counteractant Waxie Quat-128 Disinfectantcleaner Diversey Wood Wyant Expose II 256 Ultraquat Germicidal Detergent Virex II 256 Intraquat Germicidal Detergent Ecolab A-456-N A-456-N Viva Johnson Wax Intraquat Germicidal Detergent Virex Tb Intraquat Germicidal Detergent Medline Industries Intraquat Germicidal Detergent Micro-Kill Bleach Cermicidal Bleach Wipes Intraquat Germicidal Disposable Wipe Sani-Cloth HB Germicidal Disposable Cloth Intraquat Germicidal Disposable Cloth	
Diversey Wood Wyant Expose II 256 Ultraquat Germicidal Detergent Virex II 256 Image: Constraint of the second	
Expose II 256 Ultraquat Germicidal Detergent Virex II 256	
Expose II 256 Ultraquat Germicidal Detergent Virex II 256 Image: Constraint of the second	
Virex II 256 Ecolab A-456-N Viva Johnson Wax Virex Tb Medline Industries Micro-Kill Bleach Cermicidal Bleach Wipes PDI Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Disposable Cloth	
Ecolab A-456-N Viva Johnson Wax Virex Tb Medline Industries Micro-Kill Bleach Cermicidal Bleach Wipes PDI Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Disposable Cloth	
A-456-N Viva Johnson Wax Virex Tb Medline Industries Micro-Kill Bleach Cermicidal Bleach Wipes PDI Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Wipes Sani-Cloth HB Germicidal Disposable Cloth	
A-456-N Viva Johnson Wax Virex Tb Medline Industries Micro-Kill Bleach Cermicidal Bleach Wipes PDI Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Wipes Sani-Cloth HB Germicidal Disposable Cloth	
Viva Johnson Wax Virex Tb Medline Industries Micro-Kill Bleach Cermicidal Bleach Wipes PDI Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Wipes Sani-Cloth Plus Germicidal Disposable Cloth	
Johnson Wax Virex Tb Medline Industries Micro-Kill Bleach Cermicidal Bleach Wipes PDI Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Wipes Sani-Cloth Plus Germicidal Disposable Cloth	
Virex Tb Medline Industries Micro-Kill Bleach Cermicidal Bleach Wipes PDI Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Wipes Sani-Cloth Plus Germicidal Disposable Cloth	
Virex Tb Medline Industries Micro-Kill Bleach Cermicidal Bleach Wipes PDI Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Wipes Sani-Cloth Plus Germicidal Disposable Cloth	
Medline Industries Micro-Kill Bleach Cermicidal Bleach Wipes PDI Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Wipes Sani-Cloth Plus Germicidal Disposable Cloth	
Medline Industries Micro-Kill Bleach Cermicidal Bleach Wipes PDI Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Wipes Sani-Cloth Plus Germicidal Disposable Cloth	
Micro-Kill Bleach Cermicidal Bleach Wipes PDI Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Wipes Sani-Cloth Plus Germicidal Disposable Cloth	
Micro-Kill Bleach Cermicidal Bleach Wipes PDI Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Wipes Sani-Cloth Plus Germicidal Disposable Cloth	
PDI Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Wipes Sani-Cloth Plus Germicidal Disposable Cloth	
Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Wipes Sani-Cloth Plus Germicidal Disposable Cloth	
Sani-Cloth Bleach Germicidal Disposable Wipe Sani-Cloth HB Germicidal Wipes Sani-Cloth Plus Germicidal Disposable Cloth	
Sani-Cloth HB Germicidal Wipes Sani-Cloth Plus Germicidal Disposable Cloth	
Sani-Cloth Plus Germicidal Disposable Cloth	· · · · · · · · · · · · · · · · _ · · _ · · _ · · · _ · _ · _ · _ /
	· · · · · _ · · _ · · _ /
	<u> </u>
Spartan Chemical Company	
Super HDQ Neutral	<u> </u>
Steris	
TBQ	
Sysco	
Carpet & Textile Stain Digester	