

# Maintenance Guidelines

Sway  
511496

**maharam**

## Regular Maintenance

Using mild soap or detergent, machine wash on synthetic setting with a high water level and mild agitation. Temperature should not exceed 160F. Extract gently. Wash with like materials.

If necessary, machine wash with a diluted bleach solution. This textile may also be spot cleaned with a diluted bleach solution as long as the bleach solution is rinsed thoroughly after application. If bleach is used without adequate rinsing, degradation to the textile will occur.

Air, cabinet, or tumble dry at a low temperature. Do not exceed 3-5 minutes on a synthetic cycle at a maximum of 140F. Hang or fold immediately after drying.

## Hand Iron

Iron at low heat setting (275F) with a damp press cloth or steam iron with a dry press cloth.


## Grid Head Press

Press for short intervals with minimum steam. Do not lock head.

## Flat Bed Press

Press dampened drapery using cloth covering.

Avoid prolonged contact with heat.



## Notes

The information above is a guide to help in the maintenance of Maharam textiles. Maharam can neither guarantee, nor take responsibility for specific results.

Under no circumstances shall Maharam be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling, or exposure of any chemicals used in connection with maintenance. Information relating to chemicals/cleaning solvents, environmental use, and human exposure should be reviewed with appropriate suppliers. All label instructions on their use and precautions should be followed.

**Approved Cleaners**

**The Clorox Company**

Clorox Healthcare Fuzion Cleaner Disinfectant

**Various**

1:10 Solution of Diluted Household Bleach