

Maintenance Guidelines

Crush

by Lisa Scull

464780

maharam

Maintenance Code

W/S/B-Clean with water-based cleanser; mild, water-free dry cleaning solvent, or diluted household bleach.



Regular Maintenance

Vacuum regularly using the proper attachment to avoid pilling.

General Recommendations

Treat stains promptly. The longer a stain remains on the textile, the more difficult it will be to remove. A professional furniture cleaning service is recommended.

Always pre-test any cleaning method in an inconspicuous area.

Several light applications of a cleaning agent are less harmful than a single concentrated application. Repeat stain treatment several times if necessary.

Never use heat to clean textiles. Heat can set stains.

Do not over saturate the textile or let water pool in seams.

Maintenance Guidelines

Crush

by Lisa Scull

464780

maharam

Stain Treatment

Soak up any excess moisture immediately.

For water-based stains, use a clean, soft, white cloth, a natural sponge, or a nylon soft-bristle brush with lukewarm, soapy water. Brush the stain with light, quick strokes. Avoid a scrubbing motion and work from the edge of the stain toward the center.

For oil-based stains, use a clean, soft, white cloth, a natural sponge, or a nylon, soft-bristle brush with a water-free dry cleaning solvent. Brush the stain with light, quick strokes. Avoid a scrubbing motion. Work from the edge of the stain toward the center.

For tougher oil-based stains, confirm the construction of your textile is bleach cleanable. If so, and additional stain treatment is needed, use a 10% solution of diluted household bleach. Thoroughly rinse with cool, clean water and completely remove all cleaning residue.

For insoluble stains (e.g. chewing gum, candle wax, etc.), use a plastic bag filled with ice to rub the stain until the substance becomes brittle. Use a clean, dull, flat knife to gently remove the substance. If the stain persists, blot the area with a clean, soft, white cloth or natural sponge and lukewarm soapy water.

If the stain persists, gently dab a pH-neutral cleanser, upholstery spot cleaner, or an equal mixture of water and enzyme detergent (e.g. laundry detergent) on the stain and let it sit for one minute.

Rinse stain treatment thoroughly with a natural sponge moistened slightly with cool, clean water and completely remove all cleaning solution residue as left over residue can attract soil over time.

Extra care should be taken when cleaning dark colors to avoid creating light marks that can be caused by color transfer.

Avoid excess rubbing to prevent discoloration and damage to the face of the material.

Do not saturate the surface.

Allow the textile to dry thoroughly and vacuum before using.

Healthcare Recommendations

Healthcare facilities should follow safety protocols for biological hazards and/or anti-viral treatments during the cleaning process.

Always pre-test in an inconspicuous area before cleaning. After cleaning, rinse repeatedly with cool, clean water to ensure complete removal of all cleaning solution residue. Left over residue can discolor over time.

For a complete list of approved hospital grade cleansers, contact your sales representative.

Notes

The information above is a guide to help in the maintenance of bleach cleanable upholstery textiles. Maharam can neither guarantee, nor take responsibility for specific results.

Under no circumstances shall Maharam be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling, or exposure of any chemicals used in connection with maintenance. Information relating to chemicals/cleaning solvents, environmental use, and human exposure should be reviewed with appropriate suppliers. All label instructions on their use and precautions should be followed.

Maintenance Guidelines
Crush
by Lisa Scull
464780

Approved Cleaners

| |
|---|
| 3M |
| 3M HB Quat Disinfectant Cleaner Concentrate |
| 3M HB Quat Disinfectant Cleaner RTU |
| 3M Neutral Quat Disinfectant Cleaner |
| Concentrat |
| 3M Quat Disinfectant Cleaner Concentrate |

| |
|----------------------------------|
| Airx Laboratories |
| Airx 75 Rtu Disinfectant Cleaner |

| |
|---|
| Amsan |
| Sureblend Hospital Disinfectant Cleaner |

| |
|--------------------------------------|
| Avmor Ltd |
| Biomor Cleaner and Deodorizer |
| EP62 Carpet and Fabric Stain Remover |

| |
|--------------------------|
| Betco Corporation |
| FiberPRO TLC |

| |
|--|
| Bioesque Solutions |
| Bioesque Botanical Disinfectant Solution |

| |
|--|
| Brighton Professional |
| Enzyme Plus Odor Eliminator Deodorizer |

| |
|-------------------------------|
| Buckeye International |
| Sanicare Quat 256 |
| Scenturion Odor Counteractant |

| |
|--|
| Core Products |
| Unbelievable! Stain Remover and Deodorizer |

| |
|---|
| Daycon Products Company |
| Spectra System 3 Neutral Disinfectant - 310 |

| |
|-----------------|
| Diversey |
| Expose II 256 |
| Virex II 256 |
| Virex Plus |

| |
|-------------------------------|
| Ecolab |
| A-456 II Disinfectant Cleaner |
| A-456-N |

| |
|------------------------------------|
| Asepticare TB+II |
| Eco-Star Detergent |
| Oasis 146 Multi-Quat Sanitizer |
| OxyCide Daily Disinfectant Cleaner |
| Qc 31 Neutral Cleaner |
| QC 52 Glass Cleaner |

| |
|-------------------|
| HealthLink |
| CitriGuard II |

| |
|------------------------|
| Helix Solutions |
| Chlor Clean Liquid |

| |
|----------------------------|
| Hillyard Industries |
| Q.T. Plus |

| |
|--------------------|
| Johnson Wax |
| Virex Tb |

| |
|---|
| Medline Industries |
| Micro-Kill Bleach Cermicidal Bleach Wipes |

| |
|---|
| Metrex Research |
| CaviCide |
| CaviCide I |
| CaviCide Surface Disinfectant / Decontaminant |
| C |
| CaviWipes |
| CaviWipes I |
| CaviWipes XL |

| |
|----------------------|
| Nobles |
| All Puirpose Spotter |
| Brown-Ex Tannin |
| Dry Solvent |

| |
|--|
| PDI |
| Sani-Cloth Bleach Germicidal Disposable Wipe |
| Sani-Cloth HB Germicidal Wipes |
| Sani-Cloth Plus Germicidal Disposable Cloth |
| Super Sani-Cloth Germicidal Disposable Wipe |

| |
|--------------------------------------|
| RML Rochester Midland Limited |
| Proxi Spray and Walk Away |

| |
|--|
| Sensible Life Products |
| Benefect Botanical Decon 30 Disinfectant |

| |
|---------------------------------|
| Spartan Chemical Company |
| Super HDQ Neutral |

| |
|--|
| Steris |
| Coverage Plus Germicidal Surface Wipes |
| TBQ |

| |
|-------------------------------------|
| Sustainable Earth by Staples |
| 63 Concentrated Odor Eliminator |
| 64 Neutral Multi-Use Cleaner |
| 67 Carpet Spotter RTU |

| |
|-----------------------------|
| Swisher Hygiene, Inc |
| Swisher Clear |

| |
|---------------------------------|
| Sysco |
| Carpet & Textile Stain Digester |

| |
|-----------------------------------|
| The Butcher Company |
| Morning Mist Neutral Disinfectant |

| |
|---|
| The Clorox Company |
| Clorox Healthcare Bleach Germicidal Wipes |
| Clorox Healthcare Fuzion Cleaner Disinfectant |

| |
|---|
| Various |
| 1:10 Solution of Diluted Household Bleach |
| 1:4 Solution of Diluted Household Bleach |
| Water- Based Or Solvent Based Cleaners |

| |
|------------------------------------|
| Waxie Enterprises |
| Solsta 700 Disinfectant Cleaner |
| Waxie Quat-128 Disinfectantcleaner |

| |
|--------------------------------|
| Wood Wyant |
| Ed - Everyday Disinfectant |
| Ultraquat Germicidal Detergent |