

Maintenance Guidelines
Boundary
466193

maharam

Maintenance Code

W/B-Clean with water-based cleanser or diluted household bleach.



Regular Maintenance

Vacuum regularly using the proper attachment to avoid pilling. For non-woven textiles, wipe regularly with damp, clean, soft, white cloth or natural sponge.

For wallcovering products, clean with mild soap, lukewarm water and a natural sponge. Rinse with clean, clear water, and dry with a clean, soft, white cloth.

General Recommendations

Treat stains promptly. The longer a stain remains on the textile, the more difficult it will be to remove. A professional furniture cleaning service is recommended.

Always pre-test any cleaning method in an inconspicuous area.

Several light applications of a cleaning agent are less harmful than a single concentrated application. Repeat stain treatment several times if necessary.

Never use heat to clean textiles. Heat can set stains.

Do not use solvent-based cleaning agents such as lacquer thinners, nail polish remover, or pine oil. These agents may cause discoloration over time.

Do not over saturate the textile or let water pool in seams.

Maintenance Guidelines

Boundary

466193

maharam

Stain Treatment

Soak up any excess moisture immediately.

For oil and water-based stains, use a clean, soft, white cloth, a natural sponge, or a nylon soft-bristle brush with lukewarm, soapy water. Brush the stain with light, quick strokes. Avoid a scrubbing motion and work from the edge of the stain toward the center.

For tougher oil-based stains, confirm the construction of your textile is bleach cleanable. If so, and additional stain treatment is needed, use a 10% solution of diluted household bleach. Thoroughly rinse with cool, clean water to remove any residue.

For ink stains on ink resistant non-woven textiles, a 91% solution of isopropyl alcohol may also be used. Thoroughly rinse with cool, clean water to remove any residue.

For ink stains and scuff marks on vinyl wallcovering, gently blot the stain with isopropyl (rubbing) alcohol. This treatment will lighten the stain but will not remove it completely.

For solid stains (e.g. mud) allow the stain to dry thoroughly and gently break up any hardened areas. Use a nylon, soft bristle brush to remove all loose particles.

For insoluble stains (e.g. chewing gum, candle wax, etc.), use a plastic bag filled with ice to rub the stain until the substance becomes brittle. Use a clean, dull, flat knife to gently remove the substance. If the stain persists, blot the area with a clean, soft, white cloth or natural sponge and lukewarm soapy water.

For blood and bodily fluid stains, follow the oil-based stain treatment above.

If the stain persists, gently dab a pH-neutral cleanser, upholstery spot cleaner, or an equal mixture of water and enzyme detergent (e.g. laundry detergent) on the stain and let it sit for one minute.

Rinse stain treatment thoroughly with a natural sponge moistened slightly with cool, clean water and completely remove all cleaning solution residue as left over residue can attract soil over time.

Extra care should be taken when cleaning dark colors of woven textiles to avoid creating light marks that can be caused by color transfer.

Avoid excess rubbing in order to prevent discoloration and damage to the face of the material.
Do not saturate the surface.

For woven textiles, allow the textile to dry thoroughly and vacuum before using.

Healthcare Recommendations

Healthcare facilities should follow safety protocols for biological hazards and/or anti-viral treatments during the cleaning process.

Always pre-test in an inconspicuous area before cleaning. After cleaning, rinse repeatedly with cool, clean water to ensure complete removal of all cleaning solution residue. Left over residue can discolor over time.

For a complete list of approved hospital grade cleansers, contact your sales representative.

Maintenance Guidelines
Boundary
466193

maharam

Notes

The information above is a guide to help in the maintenance of Maharam textiles. Maharam can neither guarantee, nor take responsibility for specific results.

Under no circumstances shall Maharam be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling, or exposure of any chemicals used in connection with maintenance. Information relating to chemicals/cleaning solvents, environmental use, and human exposure should be reviewed with appropriate suppliers. All label instructions on their use and precautions should be followed.

Approved Cleaners

303 Products

303 Fabric / Vinyl Cleaner

A & G Industries, Inc

A & G Boat Wash & Multi Purpose Cleaner

Babe's Boat Care Products

Babe's Boat Care Wash

Bio Kleen Products

Amazing Cleaner

Boat Bling

Vinyl Sauce

CMI

V-Clean All Purpose Vinyl Cleaner

Caltech Industries

Dispatch

Diversey

Accel Prevention Concentrate

Accel Prevention Wipes

Glance NA Glass & Multi-Surface Cleaner

Non-Amm

Gp Forward SC General Purpose Cleaner

Oxivir Five 16 Concentrate

Oxivir Tb Wipes

PerCept Concentrate General Virucide

Disinfecta

Stride Floral Neutral Cleaner

Stride Fragrance Free SC Neutral Cleaner

Virex II 256

Ecolab

Asepticare TB+II

Disinfectant 1 Wipe

OxyCide Daily Disinfectant Cleaner

Kay Chemical Company

Kay Chemical Company

Lysol IC

Lysol IC Foaming Disinfectant Cleaner

Medline Industries

Micro-Kill Bleach Cermicidal Bleach Wipes

Metrex Research

CaviWipes

CaviWipes 1

CaviWipes Bleach

CaviWipes XL

Midlab, Inc

Maxim Facility +

PDI

Sani-Cloth Af 3 Germicidal Disposable Wipes

Sani-Cloth Bleach Germicidal Disposable Wipe

Sani-Cloth HB Germicidal Wipes

Sani-Cloth Plus Germicidal Disposable Cloth

Super Sani-Cloth Germicidal Disposable Wipe

Reckitt Benckiser

Lysol Disinfecting Wipes

S C Johnson & Son

Fantastik Antibacterial All Purpose Cleaner

Spartan Chemical Company

Super HDQL 10

Steris

Coverage Plus Germicidal Surface Wipes

TBQ

Stryker Medical

SideKick Disinfecting Wipes

Sunshine Makers

Crystal Simple Green Industrial Cleaner &

Degre

Tekonsha Corp

Super S

The Clorox Company

Clorox Healthcare Bleach Germicidal Wipes

Clorox Healthcare Fuzion Cleaner Disinfectant

Clorox Healthcare Hydrogen Peroxide Cleaner

Dis

Formula 409 Antibacterial All Purpose Cleaner

Triple S

Perisept # 62 Sporicidal Disinfectant Cleaner

Various

1:10 Solution of Diluted Household Bleach

1:4 Solution of Diluted Household Bleach

Water-Based Cleaners

Virox Technologies

Virox 5 Concentrate

Wexford Labs

Wex-Cide 128

Stain Test Report

Each stain is cleaned with a water-based cleanser after 1 hour and 24 hours. One stain is left untouched as a comparison control.

After each test site is cleaned and dried, the remnants of the stain are evaluated and rated in accordance with the AATCC Stain Release Evaluation Procedure.

Rating System

- 5 - Complete removal
- 4 - Good, traces of stain remain
- 3 - Moderate, 75% of stain removed
- 2 - Fair, 50% of stain removed
- 1 - Poor, less than 50% of stain removed

Type	Rating	
	1 Hour	24 hours
Ballpoint Ink *	1	1
Black Coffee	1	1
Blood	5	5
Chocolate	5	5
Cola	5	5
Iodine	1	1
Ketchup	5	5
Mayonnaise	5	5
Mustard	5	2
Red Lipstick	1	1
Red Wine	5	5
Salad Oil	5	5
Sharpie / Permanent Marker **	1	1
Shoe Polish	1	1
Suntan Lotion	5	5
Urine	5	5

* Ink was cleaned using a 91% solution of isopropyl alcohol.

** Sharpie / Permanent Marker was cleaned using a 91% solution of isopropyl alcohol.