

#### **Maintenance Code**

W/S/B-Clean with water-based cleanser; mild, water-free dry cleaning solvent, or diluted household bleach.



#### **Regular Maintenance**

Vacuum regularly using the proper attachment to avoid pilling.

#### **General Recommendations**

Treat stains promptly. The longer a stain remains on the textile, the more difficult it will be to remove. A professional furniture cleaning service is recommended.

Always pre-test any cleaning method in an inconspicuous area.

Several light applications of a cleaning agent are less harmful than a single concentrated application. Repeat stain treatment several times if necessary.

Never use heat to clean textiles. Heat can set stains.

Do not over saturate the textile or let water pool in seams.

#### **Stain Treatment**

Soak up any excess moisture immediately.

For water-based stains, use a clean, soft, white cloth, a natural sponge, or a nylon soft-bristle brush with lukewarm, soapy water. Brush the stain with light, quick strokes. Avoid a scrubbing motion and work from the edge of the stain toward the center.

For oil-based stains, use a clean, soft, white cloth, a natural sponge, or a nylon, soft-bristle brush with a water-free dry cleaning solvent. Brush the stain with light, quick strokes. Avoid a scrubbing motion. Work from the edge of the stain toward the center.

For tougher oil-based stains, confirm the construction of your textile is bleach cleanable. If so, and additional stain treatment is needed, use a 10% solution of diluted household bleach. Thoroughly rinse with cool, clean water and completely remove all cleaning residue.

For insoluble stains (e.g. chewing gum, candle wax, etc.), use a plastic bag filled with ice to rub the stain until the substance becomes brittle. Use a clean, dull, flat knife to gently remove the substance. If the stain persists, blot the area with a clean, soft, white cloth or natural sponge and lukewarm soapy water.

If the stain persists, gently dab a pH-neutral cleanser, upholstery spot cleaner, or an equal mixture of water and enzyme detergent (e.g. laundry detergent) on the stain and let it sit for one minute.

Rinse stain treatment thoroughly with a natural sponge moistened slightly with cool, clean water and completely remove all cleaning solution residue as left over residue can attract soil over time.

Extra care should be taken when cleaning dark colors to avoid creating light marks that can be caused by color transfer.

Avoid excess rubbing to prevent discoloration and damage to the face of the material.

Do not saturate the surface.

Allow the textile to dry thoroughly and vacuum before using.

#### **Healthcare Recommendations**

Healthcare facilities should follow safety protocols for biological hazards and/or anti-viral treatments during the cleaning process.

Always pre-test in an inconspicuous area before cleaning. After cleaning, rinse repeatedly with cool, clean water to ensure complete removal of all cleaning solution residue. Left over residue can discolor over time.

For a complete list of approved hospital grade cleansers, contact your sales representative.

#### **Notes**

The information above is a guide to help in the maintenance of bleach cleanable upholstery textiles. Maharam can neither guarantee, nor take responsibility for specific results.

Under no circumstances shall Maharam be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling, or exposure of any chemicals used in connection with maintenance. Information relating to chemicals/cleaning solvents, environmental use, and human exposure should be reviewed with appropriate suppliers. All label instructions on their use and precautions should be followed.

## Approved Cleaners

<b>3M</b>	<b>Medline Industries</b>	<b>Waxie Enterprises</b>
3M HB Quat Disinfectant Cleaner Concentrate	Micro-Kill Bleach Cermicidal Bleach Wipes	Solsta 700 Disinfectant Cleaner
3M HB Quat Disinfectant Cleaner RTU		Waxie Quat-128 Disinfectantcleaner
3M Neutral Quat Disinfectant Cleaner	<b>Nobles</b>	
Concentrat	All Puirpose Spotter	<b>Wood Wyant</b>
3M Quat Disinfectant Cleaner Concentrate	Brown-Ex Tannin	Ultraquat Germicidal Detergent
	Dry Solvent	
<b>Airx Laboratories</b>		
Airx 75 Rtu Disinfectant Cleaner	<b>PDI</b>	
	Sani-Cloth Bleach Germicidal Disposable Wipe	
<b>Amsan</b>	Sani-Cloth HB Germicidal Wipes	
Sureblend Hospital Disinfectant Cleaner	Sani-Cloth Plus Germicidal Disposable Cloth	
	Super Sani-Cloth Germicidal Disposable Wipe	
<b>Betco Corporation</b>		
FiberPRO TLC	<b>PURE Bioscience</b>	
	PURE Hard Surface	
<b>Bioesque Solutions</b>		
Bioesque Botanical Disinfectant Solution	<b>Sensible Life Products</b>	
	Benefect Botanical Decon 30 Disinfectant	
<b>Brighton Professional</b>		
Enzyme Plus Odor Eliminator Deodorizer	<b>Spartan Chemical Company</b>	
	Super HDQ Neutral	
<b>Buckeye International</b>		
Sanicare Quat 256	<b>Steris</b>	
Scenturion Odor Counteractant	TBQ	
<b>Daycon Products Company</b>	<b>Sustainable Earth by Staples</b>	
Spectra System 3 Neutral Disinfectant - 310	63 Concentrated Odor Eliminator	
	64 Neutral Multi-Use Cleaner	
<b>Diversey</b>	67 Carpet Spotter RTU	
Expose II 256		
Virex II 256	<b>Sysco</b>	
	Carpet & Textile Stain Digester	
<b>Ecolab</b>		
A-456-N	<b>The Clorox Company</b>	
OxyCide Daily Disinfectant Cleaner	Clorox Healthcare Bleach Germicidal Wipes	
Viva		
	<b>Various</b>	
<b>Hillyard Industries</b>	1:10 Solution of Diluted Household Bleach	
Q.T. Plus	1:4 Solution of Diluted Household Bleach	
	Water- Based Or Solvent Based Cleaners	
<b>Johnson Wax</b>		
Virex Tb	<b>Virox Technologies</b>	
	Virox 5 Concentrate	

Note: After cleaning, rinse repeatedly with cool, clean water to ensure complete removal of all cleaning solution residue. Left over residue can damage the textile over time.