

Maintenance Code

W/B-Clean with water-based cleanser or diluted household bleach.



Regular Maintenance

Vacuum regularly using the proper attachment to avoid pilling. For non-woven textiles, wipe regularly with damp, clean, soft, white cloth or natural sponge.

For wallcovering products, clean with mild soap, lukewarm water and a natural sponge. Rinse with clean, clear water, and dry with a clean, soft, white cloth.

General Recommendations

Treat stains promptly. The longer a stain remains on the textile, the more difficult it will be to remove. A professional furniture cleaning service is recommended.

Always pre-test any cleaning method in an inconspicuous area.

Several light applications of a cleaning agent are less harmful than a single concentrated application. Repeat stain treatment several times if necessary.

Never use heat to clean textiles. Heat can set stains.

Do not use solvent-based cleaning agents such as lacquer thinners, nail polish remover, or pine oil. These agents may cause discoloration over time.

Do not over saturate the textile or let water pool in seams.

Stain Treatment

Soak up any excess moisture immediately.

For oil and water-based stains, use a clean, soft, white cloth, a natural sponge, or a nylon soft-bristle brush with lukewarm, soapy water. Brush the stain with light, quick strokes. Avoid a scrubbing motion and work from the edge of the stain toward the center.

For tougher oil-based stains, confirm the construction of your textile is bleach cleanable. If so, and additional stain treatment is needed, use a 10% solution of diluted household bleach. Thoroughly rinse with cool, clean water to remove any residue.

For ink stains on ink resistant non-woven textiles, a 91% solution of isopropyl alcohol may also be used. Thoroughly rinse with cool, clean water to remove any residue.

For ink stains and scuff marks on vinyl wallcovering, gently blot the stain with isopropyl (rubbing) alcohol. This treatment will lighten the stain but will not remove it completely.

For solid stains (e.g. mud) allow the stain to dry thoroughly and gently break up any hardened areas. Use a nylon, soft bristle brush to remove all loose particles.

For insoluble stains (e.g. chewing gum, candle wax, etc.), use a plastic bag filled with ice to rub the stain until the substance becomes brittle. Use a clean, dull, flat knife to gently remove the substance. If the stain persists, blot the area with a clean, soft, white cloth or natural sponge and lukewarm soapy water.

For blood and bodily fluid stains, follow the oil-based stain treatment above.

If the stain persists, gently dab a pH-neutral cleanser, upholstery spot cleaner, or an equal mixture of water and enzyme detergent (e.g. laundry detergent) on the stain and let it sit for one minute.

Rinse stain treatment thoroughly with a natural sponge moistened slightly with cool, clean water and completely remove all cleaning solution residue as left over residue can attract soil over time.

Extra care should be taken when cleaning dark colors of woven textiles to avoid creating light marks that can be caused by color transfer.

Avoid excess rubbing in order to prevent discoloration and damage to the face of the material.
Do not saturate the surface.

For woven textiles, allow the textile to dry thoroughly and vacuum before using.

Healthcare Recommendations

Healthcare facilities should follow safety protocols for biological hazards and/or anti-viral treatments during the cleaning process.

Always pre-test in an inconspicuous area before cleaning. After cleaning, rinse repeatedly with cool, clean water to ensure complete removal of all cleaning solution residue. Left over residue can discolor over time.

For a complete list of approved hospital grade cleansers, contact your sales representative.

Notes

The information above is a guide to help in the maintenance of Maharam textiles. Maharam can neither guarantee, nor take responsibility for specific results.

Under no circumstances shall Maharam be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling, or exposure of any chemicals used in connection with maintenance. Information relating to chemicals/cleaning solvents, environmental use, and human exposure should be reviewed with appropriate suppliers. All label instructions on their use and precautions should be followed.

Approved Cleaners

3M
 3M C. diff Solution Tablets

Avmor Ltd
 Biomor Cleaner and Deodorizer
 EP62 Carpet and Fabric Stain Remover

Biotrol
 Birex SE

Brighton Professional
 Enzyme Plus Odor Eliminator Deodorizer

Clorox Professional Products Compan
 Citrace Hopsital Germicide
 Clorox Hydrogen Peroxide Disinfectant Wipe
 Clorox Hydrogen Peroxide Disinfecting Cleaner

Coastwide Laboratories
 Hepastat 256 Wipes

Diversey
 Accel Prevention Concentrate
 Accel Prevention Wipes
 Virex II 256
 Virox 5 Rtu Wipes
 Virox Ahp 5 Rtu

Ecolab
 Neutral Disinfectant Cleaner
 Oasis 146 Multi-Quat Sanitizer
 OxyCide Daily Disinfectant Cleaner

GOJO Industries
 Purell Food Service Surface Sanitizer
 Purell Healthcare Surface Disinfectant

Helix Solutions
 Chlor Clean Liquid

Johnson Diversey
 Fantastik All Purpose Cleaner

Lysol IC
 Lysol IC Foaming Disinfectant Cleaner

Metrex Research
 CaviWipes
 CaviWipes I
 CaviWipes XL

PDI
 Sani-Cloth Af 3 Germicidal Disposable Wipes
 Sani-Cloth HB Germicidal Wipes
 Sani Professional Brand Table Turners
 Sani Professional Cleaning (+ Degreasing)
 Multi
 Super Sani-Cloth Germicidal Disposable Wipe

Pct Corp.
 Hydrolyte

RML Rochester Midland Limited
 Proxi Spray and Walk Away

Russ Medical Supplies
 Fade-Adyne II

Safetec of America
 SaniZide Plus Germicidal Solution

Spartan Chemical Company
 Super HDQL 10

Sunshine Makers
 Simple Green All Purpose Cleaner

Sustainable Earth by Staples
 63 Concentrated Odor Eliminator
 64 Neutral Multi-Use Cleaner
 67 Carpet Spotter RTU

The Clorox Company
 Clorox Disinfecting Wipes
 Clorox Healthcare Bleach Germicidal Wipes
 Clorox Healthcare Ez-Kill Quat Alcohol Cleaner

Clorox Healthcare Hydrogen Peroxide Cleaner
 Dis
 Formula 409 All Purpose Cleaner
 Greenworks All-Purpose Cleaner

Triple S
 Bio-Enzymatic Spotter& Deodorant
 Perisept # 62 Sporicidal Disinfectant Cleaner

Various
 1:10 Solution of Diluted Household Bleach
 1:4 Solution of Diluted Household Bleach

Virox Technologies
 Accel Tb Wipes
 Virox 5 Concentrate

Vital Solutions
 Vital Oxide

Stain Test Report

Each stain is cleaned with a water-based cleanser after 1 hour and 24 hours. One stain is left untouched as a comparison control.

After each test site is cleaned and dried, the remnants of the stain are evaluated and rated in accordance with the AATCC Stain Release Evaluation Procedure.

Rating System

- 5 - Complete removal
- 4 - Good, traces of stain remain
- 3 - Moderate, 75% of stain removed
- 2 - Fair, 50% of stain removed
- 1 - Poor, less than 50% of stain removed

Type	Rating	
	1hr	24 hr
Ballpoint Ink *	5	4
Black Coffee	5	3
Blood	5	5
Chocolate	5	5
Cola	5	5
Iodine	4	3
Ketchup	5	5
Mayonnaise	5	5
Mustard	2	1
Red Lipstick	5	4
Red Wine	5	5
Salad Oil	5	5
Sharpie / Permanent Marker *	5	4
Shoe Polish	1	1
Suntan Lotion	5	4 **
Urine	5	5

* Ink was cleaned using a 91% solution of isopropyl alcohol.

** Surface bubbling/ blistering