

Maintenance Code

W/B-Clean with water-based cleanser or diluted household bleach.



Regular Maintenance

Vacuum regularly using the proper attachment to avoid pilling. For non-woven textiles, wipe regularly with damp, clean, soft, white cloth or natural sponge.

For wallcovering products, clean with mild soap, lukewarm water and a natural sponge. Rinse with clean, clear water, and dry with a clean, soft, white cloth.

General Recommendations

Treat stains promptly. The longer a stain remains on the textile, the more difficult it will be to remove. A professional furniture cleaning service is recommended.

Always pre-test any cleaning method in an inconspicuous area.

Several light applications of a cleaning agent are less harmful than a single concentrated application. Repeat stain treatment several times if necessary.

Never use heat to clean textiles. Heat can set stains.

Do not use solvent-based cleaning agents such as lacquer thinners, nail polish remover, or pine oil. These agents may cause discoloration over time.

Do not over saturate the textile or let water pool in seams.

Stain Treatment

Soak up any excess moisture immediately.

For oil and water-based stains, use a clean, soft, white cloth, a natural sponge, or a nylon soft-bristle brush with lukewarm, soapy water. Brush the stain with light, quick strokes. Avoid a scrubbing motion and work from the edge of the stain toward the center.

For tougher oil-based stains, confirm the construction of your textile is bleach cleanable. If so, and additional stain treatment is needed, use a 10% solution of diluted household bleach. Thoroughly rinse with cool, clean water to remove any residue.

For ink stains on ink resistant non-woven textiles, a 91% solution of isopropyl alcohol may also be used. Thoroughly rinse with cool, clean water to remove any residue.

For ink stains and scuff marks on vinyl wallcovering, gently blot the stain with isopropyl (rubbing) alcohol. This treatment will lighten the stain but will not remove it completely.

For solid stains (e.g. mud) allow the stain to dry thoroughly and gently break up any hardened areas. Use a nylon, soft bristle brush to remove all loose particles.

For insoluble stains (e.g. chewing gum, candle wax, etc.), use a plastic bag filled with ice to rub the stain until the substance becomes brittle. Use a clean, dull, flat knife to gently remove the substance. If the stain persists, blot the area with a clean, soft, white cloth or natural sponge and lukewarm soapy water.

For blood and bodily fluid stains, follow the oil-based stain treatment above.

If the stain persists, gently dab a pH-neutral cleanser, upholstery spot cleaner, or an equal mixture of water and enzyme detergent (e.g. laundry detergent) on the stain and let it sit for one minute.

Rinse stain treatment thoroughly with a natural sponge moistened slightly with cool, clean water and completely remove all cleaning solution residue as left over residue can attract soil over time.

Extra care should be taken when cleaning dark colors of woven textiles to avoid creating light marks that can be caused by color transfer.

Avoid excess rubbing in order to prevent discoloration and damage to the face of the material.
Do not saturate the surface.

For woven textiles, allow the textile to dry thoroughly and vacuum before using.

Healthcare Recommendations

Healthcare facilities should follow safety protocols for biological hazards and/or anti-viral treatments during the cleaning process.

Always pre-test in an inconspicuous area before cleaning. After cleaning, rinse repeatedly with cool, clean water to ensure complete removal of all cleaning solution residue. Left over residue can discolor over time.

For a complete list of approved hospital grade cleansers, contact your sales representative.

Notes

The information above is a guide to help in the maintenance of Maharam textiles. Maharam can neither guarantee, nor take responsibility for specific results.

Under no circumstances shall Maharam be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling, or exposure of any chemicals used in connection with maintenance. Information relating to chemicals/cleaning solvents, environmental use, and human exposure should be reviewed with appropriate suppliers. All label instructions on their use and precautions should be followed.

Approved Cleaners

3M	Ecolab	Russ Medical Supplies
3M C. diff Solution Tablets	Incidin Foam	Fade-Adyne II
3M HB Quat Disinfectant Cleaner Concentrate	Neutral Disinfectant Cleaner	
3M Neutral Cleaner Concentrate	Oasis 146 Multi-Quat Sanitizer	Safetec of America
3M Neutral Quat Disinfectant Cleaner	OxyCide Daily Disinfectant Cleaner	SaniZide Plus Germicidal Solution
Concentrat	Qc 31 Neutral Cleaner	
		SciCan
A & G Industries, Inc	GOJO Industries	OPTIM 33TB Wipes
A & G Boat Wash & Multi Purpose Cleaner	Purell Food Service Surface Sanitizer	
	Purell Healthcare Surface Disinfectant	Spartan Chemical Company
Avmor Ltd		Super HDQL 10
Biomor Cleaner and Deodorizer	Helix Solutions	
EP62 Carpet and Fabric Stain Remover	Chlor Clean Liquid	Sunshine Makers
		Simple Green All Purpose Cleaner
Biotrol	Johnson Diversey	
Birex SE	Fantastik All Purpose Cleaner	Sustainable Earth by Staples
		63 Concentrated Odor Eliminator
Brighton Professional	Lysol IC	64 Neutral Multi-Use Cleaner
Enzyme Plus Odor Eliminator Deodorizer	Lysol IC Foaming Disinfectant Cleaner	67 Carpet Spotter RTU
Buckeye International	Medline Industries	The Clorox Company
Eco Neutral Disinfectant	Micro-Kill Bleach Cermicidal Bleach Wipes	Clorox Disinfecting Wipes
		Clorox Healthcare Bleach Germicidal Wipes
Clorox Professional Products Compan	Metrex Research	Clorox Healthcare Ez-Kill Quat Alcohol Cleaner
Citrace Hopsital Germicide	CaviWipes	
Clorox Hydrogen Peroxide Disinfectant Wipe	CaviWipes I	Clorox Healthcare Hydrogen Peroxide Cleaner
Clorox Hydrogen Peroxide Disinfecting Cleaner	CaviWipes XL	Dis
		Formula 409 All Purpose Cleaner
Coastwide Laboratories	Midlab, Inc	Greenworks All-Purpose Cleaner
Hepastat 256 Wipes	Maxim Facility +	
		Triple S
Diversey	PDI	Bio-Enzymatic Spotter& Deodorant
Accel Prevention Concentrate	Sani-Cloth Af 3 Germicidal Disposable Wipes	Perisept # 62 Sporicidal Disinfectant Cleaner
Accel Prevention Wipes	Sani-Cloth HB Germicidal Wipes	
General Purpose Cleaner #15	Sani Professional Brand Table Turners	Various
Glance NA Glass & Multi-Surface Cleaner	Sani Professional Cleaning (+ Degreasing)	1:10 Solution of Diluted Household Bleach
Non-Amm	Multi	1:4 Solution of Diluted Household Bleach
Stride Floral Neutral Cleaner	Super Sani-Cloth Germicidal Disposable Wipe	Water-Based Cleaners
Stride Fragrance Free SC Neutral Cleaner		
Virex II 256	Pct Corp.	Virox Technologies
Virex Plus	Hydrolyte	Accel Tb Wipes
Virex Plus One-Step Cleaner & Deodorant		Virox 5 Concentrate
Virox 5 Rtu Wipes	RML Rochester Midland Limited	
Virox Ahp 5 Rtu	Proxi Spray and Walk Away	

Note: After cleaning, rinse repeatedly with cool, clean water to ensure complete removal of all cleaning solution residue. Left over residue can damage the textile over time.

Stain Test Report

Each stain is cleaned with a water-based cleanser after 1 hour and 24 hours. One stain is left untouched as a comparison control.

After each test site is cleaned and dried, the remnants of the stain are evaluated and rated in accordance with the AATCC Stain Release Evaluation Procedure.

Rating System

5 - Complete removal

4 - Good, traces of stain remain

3 - Moderate, 75% of stain removed

2 - Fair, 50% of stain removed

1 - Poor, less than 50% of stain removed

Type	Rating	Rating
	1 hr	24 hr
Ballpoint Ink *	5	5
Black Coffee	5	4
Chocolate	5	5
Cola	5	5
Iodine	5	4
Ketchup	5	1
Mayonnaise	5	5
Mustard	5	4
Red Lipstick	2	3
Red Wine	5	3
Salad Oil	5	4
Sharpie / Permanent Marker *	2	1
Shoe Polish	1	1
Suntan Lotion	5	4 **

* Ink was cleaned using a 91% solution of isopropyl alcohol.

** Slight surface bubbling / blistering