maharam

Maintenance Code

W/B-Clean with water-based cleanser or diluted household bleach.

 $\boxtimes \triangle \boxtimes \triangle \boxtimes$

Regular Maintenance

Vacuum regularly using the proper attachment to avoid pilling. For non-woven textiles, wipe regularly with damp, clean, soft, white cloth or natural sponge.

For wallcovering products, clean with mild soap, lukewarm water and a natural sponge. Rinse with clean, clear water, and dry with a clean, soft, white cloth.

General Recommendations

Treat stains promptly. The longer a stain remains on the textile, the more difficult it will be to remove. A professional furniture cleaning service is recommended.

Always pre-test any cleaning method in an inconspicuous area.

Several light applications of a cleaning agent are less harmful than a single concentrated application. Repeat stain treatment several times if necessary.

Never use heat to clean textiles. Heat can set stains.

Do not use solvent-based cleaning agents such as lacquer thinners, nail polish remover, or pine oil. These agents my cause discoloration over time.

Do not over saturate the textile or let water pool in seams.

maharam

Stain Treatment

Soak up any excess moisture immediately.

For oil and water-based stains, use a clean, soft, white cloth, a natural sponge, or a nylon soft-bristle brush with lukewarm, soapy water. Brush the stain with light, quick strokes. Avoid a scrubbing motion and work from the edge of the stain toward the center.

For tougher oil-based stains, confirm the construction of your textile is bleach cleanable. If so, and additional stain treatment is needed, use a 10% solution of diluted household bleach. Thoroughly rinse with cool, clean water to remove any residue.

For ink stains on ink resistant non-woven textiles, a 91% solution of isopropyl alcohol may also be used. Thoroughly rinse with cool, clean water to remove any residue.

For ink stains and scuff marks on vinyl wallcovering, gently blot the stain with isopropyl (rubbing) alcohol. This treatment will lighten the stain but will not remove it completely.

For solid stains (e.g. mud) allow the stain to dry thoroughly and gently break up any hardened areas. Use a nylon, soft bristle brush to remove all loose particles.

For insoluble stains (e.g. chewing gum, candle wax, etc.), use a plastic bag filled with ice to rub the stain until the substance becomes brittle. Use a clean, dull, flat knife to gently remove the substance. If the stain persists, blot the area with a clean, soft, white cloth or natural sponge and lukewarm soapy water.

For blood and bodily fluid stains, follow the oil-based stain treatment above.

If the stain persists, gently dab a pH-neutral cleanser, upholstery spot cleaner, or an equal mixture of water and enzyme detergent (e.g. laundry detergent) on the stain and let it sit for one minute.

Rinse stain treatment thoroughly with a natural sponge moistened slightly with cool, clean water and completely remove all cleaning solution residue as left over residue can attract soil over time.

Extra care should be taken when cleaning dark colors of woven textiles to avoid creating light marks that can be caused by color transfer.

Avoid excess rubbing in order to prevent discoloration and damage to the face of the material. Do not saturate the surface.

For woven textiles, allow the textile to dry thoroughly and vacuum before using.

Healthcare Recommendations

Healthcare facilities should follow safety protocols for biological hazards and/or anti-viral treatments during the cleaning process.

Always pre-test in an inconspicuous area before cleaning. After cleaning, rinse repeatedly with cool, clean water to ensure complete removal of all cleaning solution residue. Left over residue can discolor over time.

For a complete list of approved hospital grade cleansers, contact your sales representative.

maharam

Notes

The information above is a guide to help in the maintenance of Maharam textiles. Maharam can neither guarantee, nor take responsibility for specific results.

Under no circumstances shall Maharam be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling, or exposure of any chemicals used in connection with maintenance. Information relating to chemicals/cleaning solvents, environmental use, and human exposure should be reviewed with appropriate suppliers. All label instructions on their use and precautions should be followed.

maharam

Approved Cleaners

3M	Spartan Chemical Company	
3M HB Quat Disinfectant Cleaner Concentrate	Super HDQ Neutral	
3M HB Quat Disinfectant Cleaner RTU	· ·	
3M Neutral Quat Disinfectant Cleaner	Sustainable Earth by Staples	
Concentrat	63 Concentrated Odor Eliminator	-
3M Quat Disinfectant Cleaner Concentrate	64 Neutral Multi-Use Cleaner	
	67 Carpet Spotter RTU	
Amsan		
Sureblend Hospital Disinfectant Cleaner	Sysco	
	Carpet & Textile Stain Digester	
Brighton Professional		
Enzyme Plus Odor Eliminator Deodorizer	The Clorox Company	
	Clorox Healthcare Bleach Germicidal Wipes	
Buckeye International		
Sanicare Quat 256	Various	
	1:10 Solution of Diluted Household Bleach	
Core Products	Water-Based Cleaners	
Unbelievable! Stain Remover and Deodorizer		
	Waxie Enterprises	
Diversey	Solsta 700 Disinfectant Cleaner	
General Purpose Cleaner #15		
Glance NA Glass & Multi-Surface Cleaner	Wood Wyant	
Non-Amm	Ed - Everyday Disinfectant	
Stride Floral Neutral Cleaner	Ultraquat Germicidal Detergent	
Stride Fragrance Free SC Neutral Cleaner		
Virex II 256		
Ecolab		
A-456-N		
Eco-Star Detergent		
Enverros Fiberfresh Ultra Pro		
Qc 31 Neutral Cleaner		
Viva		
Medline Industries		
Micro-Kill Bleach Cermicidal Bleach Wipes		
201		· -
PDI		
Sani-Cloth Bleach Germicidal Disposable Wipe		
Professional Products		
Quick Fill 120	-	