

Maintenance Guidelines

Eave

466608

maharam

Maintenance Code

W/S/B-Clean with water-based cleanser; mild, water-free dry cleaning solvent, or diluted household bleach.



Regular Maintenance

Vacuum regularly using the proper attachment to avoid pilling.

General Recommendations

Treat stains promptly. The longer a stain remains on the textile, the more difficult it will be to remove. A professional furniture cleaning service is recommended.

Always pre-test any cleaning method in an inconspicuous area.

Several light applications of a cleaning agent are less harmful than a single concentrated application. Repeat stain treatment several times if necessary.

Never use heat to clean textiles. Heat can set stains.

Do not over saturate the textile or let water pool in seams.

Stain Treatment

Soak up any excess moisture immediately.

For water-based stains, use a clean, soft, white cloth, a natural sponge, or a nylon soft-bristle brush with lukewarm, soapy water. Brush the stain with light, quick strokes. Avoid a scrubbing motion and work from the edge of the stain toward the center.

For oil-based stains, use a clean, soft, white cloth, a natural sponge, or a nylon, soft-bristle brush with a water-free dry cleaning solvent. Brush the stain with light, quick strokes. Avoid a scrubbing motion. Work from the edge of the stain toward the center.

For tougher oil-based stains, confirm the construction of your textile is bleach cleanable. If so, and additional stain treatment is needed, use a 10% solution of diluted household bleach. Thoroughly rinse with cool, clean water and completely remove all cleaning residue.

For insoluble stains (e.g. chewing gum, candle wax, etc.), use a plastic bag filled with ice to rub the stain until the substance becomes brittle. Use a clean, dull, flat knife to gently remove the substance. If the stain persists, blot the area with a clean, soft, white cloth or natural sponge and lukewarm soapy water.

If the stain persists, gently dab a pH-neutral cleanser, upholstery spot cleaner, or an equal mixture of water and enzyme detergent (e.g. laundry detergent) on the stain and let it sit for one minute.

Rinse stain treatment thoroughly with a natural sponge moistened slightly with cool, clean water and completely remove all cleaning solution residue as left over residue can attract soil over time.

Extra care should be taken when cleaning dark colors to avoid creating light marks that can be caused by color transfer.

Avoid excess rubbing to prevent discoloration and damage to the face of the material.

Do not saturate the surface.

Allow the textile to dry thoroughly and vacuum before using.

Healthcare Recommendations

Healthcare facilities should follow safety protocols for biological hazards and/or anti-viral treatments during the cleaning process.

Always pre-test in an inconspicuous area before cleaning. After cleaning, rinse repeatedly with cool, clean water to ensure complete removal of all cleaning solution residue. Left over residue can discolor over time.

For a complete list of approved hospital grade cleansers, contact your sales representative.

Notes

The information above is a guide to help in the maintenance of bleach cleanable upholstery textiles. Maharam can neither guarantee, nor take responsibility for specific results.

Under no circumstances shall Maharam be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling, or exposure of any chemicals used in connection with maintenance. Information relating to chemicals/cleaning solvents, environmental use, and human exposure should be reviewed with appropriate suppliers. All label instructions on their use and precautions should be followed.

Approved Cleaners

3M
 3M General Purpose Cleaner Concentrate
 3M HB Quat Disinfectant Cleaner Concentrate
 3M HB Quat Disinfectant Cleaner RTU
 3M Heavy Duty Multi-Surface Cleaner Concentrate
 3M Industrial Degreaser Concentrate
 3M Neutral Cleaner Concentrate
 3M Neutral Quat Disinfectant Cleaner Concentrat
 3M Quat Disinfectant Cleaner Concentrate
 Scotchgard Pretreatment Cleaner Concentrate
 Scotchguard Extraction Cleaner Concentrate

Amsan
 Sureblend Hospital Disinfectant Cleaner

Betco Corporation
 FiberPRO TLC

Brighton Professional
 Enzyme Plus Odor Eliminator Deodorizer

Buckeye International
 Sanicare Quat 256

Core Products
 Unbelievable! Stain Remover and Deodorizer

Diversey
 Virex II 256
 Virex Plus

Ecolab
 A-456-N
 Eco-Star Detergent
 Enverros Fiberfresh Ultra Pro
 Oasis 146 Multi-Quat Sanitizer
 OxyCide Daily Disinfectant Cleaner
 Qc 31 Neutral Cleaner
 Viva

Spartan Chemical Company
 Super HDQ Neutral

Sustainable Earth by Staples
 63 Concentrated Odor Eliminator
 64 Neutral Multi-Use Cleaner
 67 Carpet Spotter RTU

Sysco
 Carpet & Textile Stain Digester

The Clorox Company
 Clorox Healthcare Fuzion Cleaner Disinfectant

UVC Light
 Uvc Light Disinfectant

Various
 1:10 Solution of Diluted Household Bleach
 1:4 Solution of Diluted Household Bleach
 Water-Based Cleaners
 Water- Based Or Solvent Based Cleaners

Waxie Enterprises
 Solsta 700 Disinfectant Cleaner
 Waxie Quat-128 Disinfectant cleaner

Wood Wyant
 Ed - Everyday Disinfectant
 Ultraquat Germicidal Detergent