

Maintenance Guidelines

Cubist

511482

maharam

Regular Maintenance

Using mild soap or detergent, machine wash on synthetic setting with a high water level and mild agitation. Temperature should not exceed 160 F. Extract gently. Do not use bleach or fabric softener. Wash with like materials.

Air, cabinet, or tumble dry at a low temperature. Do not exceed 3-5 minutes on a synthetic cycle at a maximum of 140 F. Hang or fold immediately after drying. Open weave draperies such as casements, sheers, and leno weaves can also be air or cabinet dried on a pin frame or curtain stretcher.

Hand Iron

Iron at low heat setting (275 F) with a damp press cloth or steam iron with a dry press cloth.

Grid Head Press

Press for short intervals with minimum steam. Do not lock head.

Flat Bed Press

Press dampened drapery using cloth covering.

Avoid prolonged contact with heat.

Notes

The information above is a guide to help in the maintenance of Maharam textiles. Maharam can neither guarantee, nor take responsibility for specific results.

Under no circumstances shall Maharam be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling, or exposure of any chemicals used in connection with maintenance. Information relating to chemicals/cleaning solvents, environmental use, and human exposure should be reviewed with appropriate suppliers. All label instructions on their use and precautions should be followed.