

Maintenance Guidelines
Double Eclipse
283862

maharam

Regular Maintenance

Remove all hardware and fully open tape pleats before washing.

Using mild soap or detergent, machine wash on synthetic setting with a high water level and mild agitation. Do not use a spin cycle. Temperature should not exceed 85 F. Extract gently. Do not use bleach or fabric softener. Wash with like materials.

Remove immediately from machine and air dry open to full width without coated faces coming into contact. Do not tumble dry.

Hand Iron. Iron at low heat setting (230 F) with a damp press cloth or steam iron with a dry press cloth. Only iron fabric face. Do not iron back coating. Do not dry clean.

Do not press with grid head press or flat bed press.

The information above is a guide to help in the maintenance of bleach cleanable upholstery textiles. Maharam can neither guarantee, nor take responsibility for specific results.

Under no circumstances shall Maharam be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling, or exposure of any chemicals used in connection with maintenance. Information relating to chemicals/cleaning solvents, environmental use, and human exposure should be reviewed with appropriate suppliers. All label instructions on their use and precautions should be followed.